

OBSOLETE AND LESS POPULAR TUBES

TUBE TYPE	SET CONTROLS*				
	A	B	C	U	D
00A	2	5	30	23	4
01A	2	5	45	23	4
0A2	4	OFF	40	15	247
1A6 Tests 1-2	2-1	2	50-55	34-250	6-6
1B4	1	2	27	230	7
1F4	3	2	47	234	5
1F5	2	2	36	345	7
1F6 Tests 1-2	1-1	2	37-95	230-4	6-6
1F6 Test 3	1	2	95	5	6
1F7 (1F7GV)	1	2	35	360	7
1F7 Tests 2-3	1-1	2	95-95	5-4	7-7
2A5 (KR-25)	3	2.5	36	234	56
2A6 Tests 1-2	3-1	2.5	56-40	20-4	56-56
2A6 Test 3	1	2.5	40	3	56
2C22	3	6.3	22	0	78
(Short Top Caps Together)					
2E24	3	2.5	22	350	27
(In Short Test, Levers 1, 4 and 6 Should Show Short, When Moved to "U" Position)					
2S/4S (G-2)	1	2.5	45	3	45
2S/4S Test 2	1	2.5	45	2	45
6Y3G	4	6.3	47	0	7
6Y5 Tests 1-2	3-3	6.3	28-28	3-5	46-46
6Z3	3	6.3	24	2	34
7A4 (XXL)	2	6.3	24	26	78
7A5	3	6.3	23	236	78
7B4	1	6.3	22	26	78
7B5	3	6.3	29	236	78
7C4/1203A	2	6.3	33	4	78
10	3	7.5	56	23	4
10Y	3	7.5	42	23	4
12A	2	5.0	26	23	4
12B4	2	6.3	20	279	145
12B6 Tests 1-2	3-1	12.6	31-58	30-4	78-78
12B6 Test 3	1	12.6	58	5	78
14	2	12.6	30	230	45
14Y4 Tests 1-2	3-3	12.6	28-28	3-6	78-78
14Z3	3	12.6	25	2	34
15	2	2	36	230	45
17	3	12.6	40	23	45
18	3	12.6	31	234	56
19 Tests 1-2	3-3	2	37-39	23-45	6-6
20	2	6.3	48	23	4
20J8 Tests 1-2	1-1	19.6	20-19	56-3450	78-78
21A6	3	19.6	16	1267890	35
(No open element test on pin 0)					
22	1	2.5	56	230	4

TUBE TYPE	SET CONTROLS*				
	A	B	C	U	D
24A	2	2.5	32	230	45
25A6	3	25	27	345	78
25A7 Tests 1-2	3-3	25	27-23	345-6	78-17
25B5 Tests 1-2	3-3	25	37-46	24-34	56-256
25B6	3	25	23	345	78
26	2	1.4	38	23	4
27	2	2.5	32	23	45
28D7 Tests 1-2	2-2	25	22-22	234-357	68-68
28Z5 Tests 1-2	3-3	12.6	38-38	3-6	187-47
29	2	2.5	36	23	456
30	2	2	35	23	4
31	2	2	40	23	4
32	2	2	42	230	4
32L7 Tests 1-2	3-3	32	21-18	345-6	78-17
33	3	2	39	234	5
34	2	2	40	230	4
35 (51)	2	2.5	30	230	45
36	2	6.3	32	230	45
37	3	6.3	37	23	45
38	3	6.3	36	230	45
39 (44)	2	6.3	30	230	45
40	1	5	28	23	4
40Z5* (45Z5)	3	32	20	5	238
41	3	6.3	32	234	56
42	3	6.3	29	234	56
43	3	25	31	234	56
45	3	2.5	32	23	4
45Z3	3	50	24	26	47
46	3	2.5	35	234	5
47	3	2.5	41	234	5
48	3	32	25	234	56
49	2	2	38	234	5
50 (585)	3	7.5	42	23	4
52	3	6.3	30	234	5
53 Tests 1-2	3-3	2.5	32-32	23-56	47-47
55 Tests 1-2	2-1	2.5	32-40	20-3	56-56
55 Test 3	1	2.5	40	4	56
56	2	2.5	30	23	45
57	2	2.5	30	230	456
57A (AS)	3	6.3	34	230	456
58	3	2.5	35	230	456
58AS	3	6.3	35	230	456
59	3	2.5	29	2345	67
64	1	6.3	22	230	45
65	2	6.3	28	230	45
67	3	6.3	37	23	45

TUBE TYPE	SET CONTROLS*				
	A	B	C	U	D
68	3	6.3	37	230	45
70A7	3	70	23	345	678
70A7 Test 2	3	70	20		167
(Allow Tube to Heat Up, Return Levers 6 and 7 to "U" Position. Good Tube Will Kick to 70)					
71A	3	5	47	23	4
72	4	2.5	35	0	4
75 Tests 1-2	1-1	6.3	20-38	20-3	56-56
75 Test 3	1	6.3	38	4	56
76	2	6.3	33	23	45
77	2	6.3	30	230	456
78	3	6.3	31	230	456
79 Tests 1-2	3-3	6.3	30-30	23-50	46-46
80 Tests 1-2	3-3	5	55-55	2-3	4-4
81	3	7.5	75	2	4
82 (82V)	3	2.5	24	2	4
82 Test 2	3	2.5	24	3	4
83 (83V)	3	5	26	2	4
83 Test 2	3	5	26	3	4
85 Tests 1-2	3-1	6.3	45-47	20-3	56-56
85 Test 3	1	6.3	47	4	56
86M	3	6.3	37	35	78
87S	2	6.3	33	230	456
88 Tests 1-2	3-3	5	26-26	2-3	4-4
88M	3	6.3	31	340	578
88S	3	6.3	32	230	456
89	3	6.3	32	230	56
89 RS 1 & 2	3-1	6.3	36-24	20-4	357-37
89 RS Test 3	1	6.3	24	6	37
95	3	2.5	36	234	56
98 Tests 1-2	3-3	6.3	26-26	2-3	45-45
99 (99X/X99)	2	2.5	65	23	4
99V/V99	2	2.5	65	13	4
128A/2523N1	4	2.5	20	23	45
182B (482B)	3	5	37	23	4
183 (483)	3	5	40	23	4
210T	3	7.5	56	23	4
230S	2	2	35	23	4
233S	3	2	39	234	5
234S	2	2	40	230	4
257A	2	2.5	41	20	4
262B	3	7.5	42	20	34
274A Tests 1-2	3-3	5	36-36	2-3	4-4
427	3	2.5	44	23	45
484 (485)	3	2.5	32	23	45
486	2	2.5	48	23	45
713-A	2	6.3	25	468	357

*Tapped Filaments—See Instructions.

ALLIED RADIO CORP.
100 NORTH WESTERN AVE
CHICAGO 80, ILLINOIS

TUBE DATA SUPPLEMENT LIST

The following list of tubes that may be checked on the Knight Kit tube Checker Supplements the last printing of the roll chart (Sept. 1956).

A few tube types have been announced but do not appear on this chart because they can be properly checked only on the most expensive types of tube checker.

OA4	Tests 1-2	4-4	off	40-44	7-5	25-27
OZ4	Tests 1-2	4-4	off	22-22	5-3	38-58
1AH5/DAF96		1	1.4	32	456	37
1AH5/DAF96	Test 2	1	1.4	53	3	1
1S2-A		1	1.4	90	0	1469
	(Good Tube Reads	35)				
2B3		3	2.0	100	0	2
	(Good Tube Reads	10)				
2B5	Tests 1-2	1-1	2.0	22-22	13-68	45-45
3AF4	2	3.0		62	17	2356
3BN4	2	3.0		20	27	136
3BU8	1	3.0		20	2367	15
3BU8	Test 2 1	3.0		20	2789	15
3LE4	2	1.4		34	236	18
3LF4*	2	1.4		30	236	18
4AU6	2	4.2		22	1256	47
4BA6	2	4.2		23	1256	47
4BC5	1	4.2		18	156	237
4BC8	2	4.2		20	12	34
4BC8	Test 2 2	4.2		20	67	48
4BE6	Test 1-2 2-1	4.2		20-26	16-57	24-24
4BN6	1	4.2		36	2567	13
	(Good = 23)					
4BS8	Tests 1-2 2-2	4.2		22-22	12-67	34-48
4BU8	1	4.2		20	2367	15
4BU8	Test 2 1	4.2		20	2789	15

4BX8	Test 1-2	1-1	5.0	19-19	12-67	35-58 ²⁾
4BZ8	Tests 1-2	3-3	4.2	16-16	67-12	58-35
4CB6		2 (No open elements	4.2	22 Tests on Pins 5, 7)	1567	23
4CE5		2 (No open element	4.2	20 Test On Pin 5)	156	<u>247</u>
4CY5		1	5.0	48	56	<u>1247</u>
4DT6		1	4.2	17	1567	<u>24</u>
5AS8	Tests 1-2	3-2	5.0	15-20	129-6	<u>34-48</u>
5BE8	Tests 1-2	2-2	5.0	20-20	12-679	35-358
5BQ7A	Tests 1-2	2-2	5.0	19-19	12-67	<u>34-48</u>
5BS8	Tests 1-2	2-2	5.0	22-22	12-67	<u>34-48</u>
5BT8	Tests 1-2	1-1	5.0	27-25	1-2	35-35
5BT8	Test 3	1	5.0	18	678	<u>59</u>
5BZ7	Tests 1-2	3-3	5.0	19-19	12-67	<u>34-48</u>
5CL8	Tests 1-2	2-2	5.0	21-21	12-679	<u>34-48</u>
5CM6		3	5.0	21	1369	<u>47</u>
5CQ8	Tests 1-2	1-1	5.0	19-19	19-236	58-57
5CZ5		1	5.0	21	1369	57
5DH8	Tests 1-2	1-2	5.0	19-20	12-679	<u>34-58</u>
6AM5/EL91		1	6.3	22	157	<u>24</u>
6BA8A	Tests 1-2	3-3	6.3	20-16	23-789	<u>14-46</u>
6BE8A	Tests 1-2	2-2	6.3	20-20	12-679	35-358
6BM8	Tests 1-2	1-1	6.3	20-20	19-367	58-25
6BR5	EYE OP	4	6.3	0	127	4
6BR5	EYE CL	4	6.3	0	12	<u>4</u>
(No open element Test on Pins 1,2,7)						
6BS8	Tests 1-2	2-2	6.3	22-22	12-67	<u>34-48</u>
6BU8	Tests 1-2	1-1	6.3	20-20	2789-2367	15-15
6BV8	Tests 1-2	2-1	6.3	20-60	23-9	15-57
6BV8	Test 3	1	6.3	60	6	<u>58</u>
6BW8	Tests 1-2	1-1	6.3	17-17	689-1	47-234
6BW8	Test 3	1	6.3	17	3	<u>-124</u>

		1	6.3	19	2789	3) 135
6BY7		(No shorts Test on 1 and 3) (No element Test on 1 and 3)				
6BY8	Tests 1-2	2-2	6.3	26-22	1278-6	59-35
6BZ8	Tests 1-2	3-3	6.3	16-16	67-12	58-35
6CK4		1	6.3	21	<u>135</u>	<u>78</u>
6CL8	Tests 1-2	2-2	6.3	21-21	12-679	<u>34-48</u>
6CM7	Tests 1-2	2-2	6.3	22-24	18-67	59-35
6CQ8	Tests 1-2	1-1	6.3	19-19	19-236	58-57
6CU8	Tests 1-2	1-1	6.3	20-19	89-237	15-56
6CW5		3	6.3	16	126789	<u>34</u>
6CX8	Tests 1-2	1-2	6.3	20-23	23-789	<u>14-56</u>
6CY7		1	6.3	21	67	58
6CY7	Test 2	(2 and 3 also show short) 1	6.3	20	<u>123</u>	59
6CZ5		1	6.3	21	<u>1369</u>	57
6DB5		3	6.3	20	<u>1369</u>	<u>247</u>
6DE7	Tests 1-2	1-1 (2 and 3 also show short)	6.3	21-22	<u>123-67</u>	59-58
6DK6		2	6.3	20	1567	<u>24</u>
6DL7 EYE OP		4	6.3	0	5	<u>478</u>
6DL7 EYE C1		4	6.3	0	<u>356</u>	<u>478</u>
		(No open element test)				
6DQ6GA		3	6.3	17	450	<u>78</u>
6IS5		1	6.3	19	<u>1567</u>	<u>24</u>
8AU8	Tests 1-2	2-2	7.5	22-22	23-789	<u>14-46</u>
8AW8	Tests 1-2	1-2	7.5	19-20	23-789	15-56
8BA8A	Tests 1-2	1-2	7.5	18-19	23-789	15-56
8BH8	Tests 1-2	1-2	7.5	22-22	23-789	<u>15-56</u>
8BN8	Tests 1-2	1-2	7.5	20-23	78-1	<u>49-24</u>
8BN8	Test 3	2	7.5	34	6	<u>14</u>
8CG7	Tests 1-2	2-2	7.5	22-22	12-67	<u>34-48</u>
8CM7	Tests 1-2	2-3	7.5	23-25	18-67	<u>59-35</u>

8CX8 Tests 1-2	1-1	7.5	21-21	789-23	<u>46-14</u>	4)
8CY7 Tests 1-2	1-1	7.5	20-22	<u>123</u> -67	<u>59-58</u>	
8SN7 Tests 1-2	2-2	7.5	25-25	12-45	<u>38-68</u>	
9AU7 Tests 1-2	2-2	5.0	23-23	12-67	3 <u>45-45</u> 8	
12AB5	3	12.6	23	1368	<u>57</u>	
12AC6	1	12.6	21	256	<u>47</u>	
12AD6	1	12.6	32	6	12357	
12AD6 -Test 2	1	12.6	32	567	<u>123</u>	
12AE5	1	12.6	22	17	<u>23</u>	
12AE6 -Test 2	1	12.6	40	6	<u>23</u>	
12AE6 -Test 3	1	12.6	40	5	<u>23</u>	
12AF6	1	12.6	34	56	1237	
12AJ6	1	12.6	20	17	<u>23</u>	
12AJ6 - Test 2	1	12.6	38	6	<u>23</u>	
12AJ6 - Test 3	1	12.6	38	5	<u>23</u>	
12AL8	1	12.6	22	1	<u>59</u>	
12AL8 - Test 2	1	12.6	38	26	<u>357</u>	
12BV7	1	6.3	19	23789	<u>16</u>	
12BW4 Tests 1-2	4-4	12.6	20-20	7-1	<u>59-59</u>	
12CN5	2	12.6	42	67	<u>1235</u>	
12CR6 Tests 1-2	2-1	12.6	23-36	567-2	<u>14-14</u>	
12CT8 Tests 1-2	2-3	12.6	22-16	12-678	<u>34-59</u>	
12CX6	1	12.6	24	256	<u>147</u>	
12CX8	1	12.6	23	256	<u>137</u>	
12DB5	2	12.6	24	<u>1369</u>	<u>247</u>	
12DF5 Tests 1-2	1-1	6.3	31-31	1-6	<u>39-89</u>	
12DQ6	3	12.6	16	450	<u>78</u>	
12DW5	1	12.6	21	<u>1369</u>	<u>57</u>	
12EA6	1	12.6	25	56	<u>1247</u>	
12EC8 Tests 1-2	1-1	12.6	40-57	2-67	<u>135-589</u>	
12EL6 Tests 1-2	1-1	12.6	40-35	2-5	<u>147-47</u>	
12EL6 Test 3	1	12.6	35	6	<u>47</u>	

12EN6	1	12.6	19	345	78	5)
12J8 Tests 1-2	1-1	12.6	20-20	136-8	24-47	
12J8 Test 3	1	12.6	20	9	<u>47</u>	
17AV5	3	19.6	16	158	<u>23</u>	
17AX4	3	19.6	20	5	<u>38</u>	
17DQ6	3	19.6	15	450	<u>78</u>	
18AK5	1	19.6	21	156	<u>247</u>	
18AQ5	1	19.6	23	<u>1567</u>	<u>24</u>	
18C51 Tests 1-2	1-1	19.6	20-20	34-67	<u>256789</u>	<u>-234589</u>
18J6 Tests 1-2	1-1	19.6	23-23	16-25	<u>2457</u>	<u>-1467</u>
25DN6	3	25	17	580	<u>37</u>	
EL-34	3	6.3	25	345	<u>78</u>	
GZ34/5AR4 Tests 1-2	3-3	5.0	16-16	6-4	<u>8-8</u>	
35CD6	3	32	17	580	<u>23</u>	
EL36	3	6.3	20	50	<u>7</u>	
PL 36	3	25	16	145	<u>378</u>	
EL-37	3	6.3	27	345	<u>78</u>	
ECC81 Tests 1-2	2-2	6.3	21-21	12-67	<u>39-89</u>	
EZ81 Tests 1-2	3-3	6.3	20-20	1-7	<u>34-34</u>	
ECC82 Tests 1-2	2-2	6.3	25-25	12-67	<u>39-89</u>	
ECC83 Tests 1-2	1-1	6.3	20-20	12-67	<u>345-458</u>	
EL84/6BQ5	1	6.3	20	<u>1279</u>	<u>35</u>	
EF86	1	6.3	20	1689	<u>35</u>	
(No open element Test on Pin 6)						
6973	1	6.3	21	<u>1369</u>	<u>57</u>	

3LF4* is Tapped filament